


Operator's Manual and Parts Catalog

THRED-O-MATIC®

66-A



WARNING

Before operating this unit, read and understand the Operator's Manual. Become familiar with the potential hazards of this unit.

ROTHENBERGER

INDEX

Adapter Assembly, Small Die Head	14	Operating Procedure	2
Blade Reamer Assembly	11	Operator Safety Instructions	1
Brake-Band Assembly	11	Preparing for Operation	2
Carriage Assembly	14	Snap-O-Matic Die Head Assemblies	13
Cone Reamer Assembly	10	Specifications	2
Cutter Assembly, Wheel Type	10	Spindle Assembly	11
Die Head Adjustment	4	Transmission Assembly—Exploded	
Die Segment Index	17-19	View	8
Groover Head Assemblies	12	Transmission Assembly—Parts	9
Lubrication and Maintenance	4	Thread Sizes & Specifications	20
Main Assembly—Exploded Views	6	Warranty	Inside Cover
Main Assembly—Parts	7	Wiring Diagram	16
Oil Line Schematic	15		

OPERATOR SAFETY INSTRUCTIONS

WARNING: This metalworking machine is designed for threading, cutting, reaming, beveling and grooving pipe with accessories made or authorized by Rothenberger. Modifying machine in any way and/or using devices not made or authorized by Rothenberger can result in serious injury and void Rothenberger's warranty and liability.

REMEMBER:

- * Operate machine from switch side only.
- * Do not disconnect or block footswitch.
- * Do not wear gloves, loose clothing or neckties.

1. Read and understand the Instruction Manual. Before operating or performing maintenance on this machine, read carefully the operator's manual. Become familiar with the machine's operations, applications and limitations. Be particularly aware of its specific hazards. Store the operator's manual in a clean area and always at a readily available location.
2. Inspect the equipment. Prior to starting the machine, check the movable parts for obstructions, such as rags, packing remnants, etc. Be certain that guards and machine parts are properly installed and secured.
3. Prevent accidental startings. Place switch in "OFF" position prior to plugging in machine.
4. Ground the machine. Be certain the machine is connected to an internally grounded electrical system.
5. Keep work area clean. Keep the work area adjacent to the machine clear of clutter for unobstructed movement of the operator. Remove all oil or coolant spills. Remove shavings from chip tray as required to maintain proper operating clearance.
6. Use pipe supports. It is mandatory to use floor mounted pipe stands for long, heavy work.
7. Wear proper clothing. Loose clothing can get easily tangled in moving parts. When operating machine, do not wear unbuttoned jackets, loose sleeve cuffs, gloves, neckties, long hair, etc. Safety glasses and shoes should be worn.
8. Secure machine and work. Make certain that the machine is bolted to a heavy work bench or proper stand.
9. Always maintain machine. Keep machine clean and cutting tools sharp for safe, dependable operation. Follow lubricating instructions. Report any unsafe condition for immediate correction.
10. Keep alert. Do not operate machine if ill or drowsy from medication or fatigue. Avoid horseplay around equipment and keep bystanders a safe distance from equipment.
11. Operate on switch side only. Machine should be operated on switch side only. Never reach across

moving parts or material being worked on. Switch should always be accessible to operator.

12. Operate in proper environment. Machine should not be operated in damp locations. Wear hearing protection in noisy shop environments. Insure proper illumination in work area.
13. Do not misuse machine. Perform only the functions for which the machine is designed. Do not force machine.
14. Disconnect power cord prior to servicing. Repair should be attempted only by authorized personnel. Always disconnect power cord before making any adjustments or servicing the machine.
15. Do not operate the machine with the spindle cover removed.
16. Keep fingers and hands away from the chucking jaws.
17. Keep visitors away. All visitors should be kept a safe distance from work area.
18. Use only recommended accessories. Refer to Operator's Manual. Use of improper accessories may be hazardous.
19. Caution: Do not allow familiarity gained from frequent use of your machine to become commonplace. Always remember that a careless fraction of a second is sufficient to inflict severe injury.

MACHINERY CAN MAIM

Keep Covers In Place!



SPECIFICATIONS

Motor: 220-440 V., 3 Phase, 60 Cycle 5 H.P., 1170 RPM, AVO-213 Frame or 220 V., 1 Phase, 60 Cycle 3 H.P., 1800 RPM, RVO-254 Frame.

THREADING RANGE:

Pipe or conduit: 2½"-6"

With adapter and small die head: 1"-6"

Bolt: 2½"-4"

With adapter and small die head: 1"-4"

Switch: 3 Station Pushbutton with Magnetic Starter and Overload Switch.

Weight: 1610 lbs. with 2 die heads less optional equipment.

Clearance required to service and operate:

Front and back: 3'

Left Side: 22' (Full length of pipe)

Right Side: 8.5'

Foundation: No special requirement.

Fusing required: Single Phase, 21 amp., Three Phase, 10 Amp.

DIMENSIONS

Length 48¾"

Width 29¾"


Height 45¾"

Floor to center line of spindle 36¾"

PREPARING FOR OPERATION

MOUNTING

While it is not essential to bolt the THRED-O-MATIC "66-A" to the floor, bolt holes are provided in the base for a solid and permanent installation. The mounting pads on the motor end of the "66-A" are made thicker to provide for proper oil drainage out of the pipe. Care should be taken in mounting machine to maintain the height differential.



POWER

Use proper electric current as shown on the name plate. Always connect the ground wire to the outlet box.

To prevent power loss, extension cord of sufficient capacity must be used:

POWER	CORD LENGTH	WIRE SIZE
220 V. Single Phase	Below 50'	10-3
	50'-100'	8-3
220 V. Three Phase	Below 50'	14-4
	50'-100'	10-4
440 V. Three Phase	Below 50'	14-4
	50'-100'	10-4

OVERLOAD SWITCH

On the THRED-O-MATIC "66-A" an automatic cut-off is actuated to protect the motor in event of under-or overloading of power. To reset, open door of machine and push reset button.

OIL PUMP

Pour five gallons of THRED-O-MATIC oil into the THRED-O-MATIC "66-A" sump. If THRED-O-MATIC oil is not available, use an equivalent dark, sulphur base thread cutting oil. Be sure level is above oil strainer.

Collins threading oil is a special oil designed to stand up under the high speed operation of this machine. Other oils will have a tendency to break down, thereby causing excessive die wear.

The cutting oil control valve is located on the front panel just below the push button switch. Turn counter-clockwise to decrease and clockwise to increase oil flow.

OPERATING PROCEDURE

DOUBLE AUTOMATIC CHUCK

NOTE: Never, under any circumstances, shift gears while motor is running.

1. Press 'reverse' button to open jaws.
2. Put stock in machine.
3. Select proper speed according to instruction plate above shifting lever.
4. Press "forward" button to close jaws and start rotating stock.

For maximum power, machine is engineered for direct drive, without a clutch. Occasionally gears may not mesh when shifting. Simply touch the "reverse" button to move gears slightly, then shift gears.

THREAD CUTTING

1. Slip the proper size die head onto the carriage pin, and lower the head into the carriage groove. The THRED-O-MATIC "66-A" carriage is designed so that die head adapter can be mounted for use with 2" and smaller die heads.
2. On Mono, Dual, Uniquad and Scroll

- heads, close operating handle; on Snap-O-Matic heads, select the correct size and engage the operating handle pin.
3. On die heads with reamers attached, be sure reamer is in die head with number side up.
 4. Insert stock through the spindle from either the front or rear of the machine.
 5. Select proper speed as shown on the instruction plate.
 6. Actuate switch to "on" position to close jaws and rotate stock.
 7. Manually feed die head onto the stock, using pressure, until a few threads have been cut, after which head automatically feeds itself.
 8. Correct thread length is normally obtained when stock reaches the outside edge of chasers, at which time open die head with right hand. With left hand, move carriage away from stock. The machine is also equipped with a thread length scale.

REAMING

Die heads with reamers attached:

1. Be sure number side of reamer is up.
2. Reaming is accomplished while threading, in one operation.
3. If reaming only is desired, open die head and move carriage forward. Ream to desired depth.

Dual or Uniquad die heads:

1. Reaming is accomplished as a separate operation.
2. Open die head, move reamer forward. Ream to desired depth. It is best to ream the pipe before threading.

CUTTING

1. Select proper speed as shown on the instruction plate.
2. Be sure cutting assembly is centered and open.
3. Insert stock. Move carriage until cutter wheel is at the point where cut is desired. Turn cutter handle clockwise for cut-off.

NOTE: Never cut into threads, as this may cause damage to the cutting wheel.

GROOVING

1. Install grooving head on carriage pin.
2. Turn grooving feed screw handle (11) counter-clockwise as far as it will go to

get cutting tool completely clear of the pipe.


3. Shift transmission to the number 1 position and chuck material in machine to be grooved and cut.
4. Pass grooving head over material and place operating lever pin in the appropriate setting on the selector plate (19) to match the size of the material you are going to groove and cut. This will align pipe and grooving head.
5. Adjust centering bolt (24) for proper seat in carriage and tighten lock nut (23).
6. With machine running in the number 1 position, turn feed screw handle (11) clockwise to engage cutting tool (18) with pipe. Before proceeding to cut material, tighten screw on rear of carriage. This will keep carriage from creeping.
7. When using tool on standard wall pipe, the cutting tool will first part the material. After material has parted, while keeping the machine running, turn feed screw handle (11) one complete revolution until marks line up on indicator (13) and bearing block (21) which will give the proper depth of groove.
8. After the groove is finished, turn the feed screw handle (11) counter-clockwise to open position again.
9. Open operating lever and remove pipe.
10. Check frequently to be certain grooving tool has not become dull and needs sharpening; use groove depth scale or coupling for this purpose. Visually you may determine signs of a dull or improperly sharpened cutting tool if you notice excessive burr on pipe after cutting.

MAKE-ON SEE FIGURE 1

Insert the pipe either from the front or rear of machine and start the machine. Apply "Joint dope", and place fitting in position using a wrench or other holding device. Let the machine screw the fitting in place.


BREAKDOWN SEE FIGURE 2

Old tight fittings can be broken loose at the rear of the machine. The THRED-O-MATIC



MAKE-ON (Figure 1)

"66-A" has an extension bar on the rear for this purpose.



BREAKDOWN (Figure 2)

DIE HEAD ADJUSTMENT

REFER TO DRAWINGS

Your machine is equipped with die heads which have been adjusted to standard thread gauges at the factory. If a "deeper" (undersize) or "shallower" (oversize) thread is desired:

1. Mono, Dual and Uniquad heads — Loosen locking lever of locking nut and rotate scroll plate in the direction indicated on link or housing.
2. Snap-O-Matic heads — Loosen two screws and move selector plate in the direction indicated on the selector plate.

To change dies:

1. Mono, Dual and Uniquad heads — Loosen locking lever or locking nut, rotate scroll plate until cam slots line up with entry slots in die head.
Snap-O-Matic heads — Remove scroll plate stop, rotate scroll plate until cam slots line up with entry slots in die head.
2. Check numbers of dies to be installed. A set consists of five (5) die segments numbered 1 to 5 for pipe size 2½" - 4". Dies for smaller pipe sizes contain four

- (4) die segments numbered 1 to 4.
3. Install dies in die head, matching the numbers on the die with the numbers on the die head. Rotate scroll plate to proper pipe size.

LUBRICATION AND MAINTENANCE

REFER TO MAIN ASSEMBLY

PUMP LUBRICATION

CUTTING OIL

To assure clean threads and long wear on chasers use Collins sulphur base cutting oil. Change every forty hours of operation. Three of the main causes of poor threads are either a poor grade of cutting oil, cutting oil that has lost its coolant qualities through over-use, or water in the sump.

CARRIAGE RAILS (35) AND GEAR (37)

Keep clean and oil frequently with machine oil.

OIL PRESSURE RELIEF VALVE (57)

Located next to the strainer in the sump. Should be cleaned periodically to avoid loss of oil pressure through die head. To readjust, turn set screw clockwise as far as it will go and then back one complete turn.

SPINDLE GEAR (5)

Remove spindle cover and check ring gear every six months to see if additional "Fil-Mo-Plate" spray lubricant needs to be applied.

TRANSMISSION (46)

Remove spindle cover and check transmission oil level every thirty days. Change oil after the first 100 hours of operating, use SAE 40 gear oil. Thereafter, drain and replace with 1½ quarts of oil every six months.

V-belts should be adjusted so that when fingers are placed across the two belts and squeezed, there should be at least ½-inch movement in the belts.

MOTOR (62)

Check single phase motors for brush wear every six months. If motor lacks power due to a dirty commutator, use a commutator cleaner

stick or fine emery cloth.

Lubrication is not required as all motors have sealed ball bearings.

DIES

Keep sharp and free of chips at all times. Sharpening service is provided at the factory for a nominal charge. As all sets of dies are matched, send in complete set for sharpening. When replacing dies in the die head, make sure the number of each die corresponds with the slot number on the die head.

JAWS


Keep clean with wire brush to avoid slippage. When replacing chuck jaws be sure the "R" markings on the jaws are toward the rear or motor end of the machine.

BRAKE BAND (18)

If slippage of stock should still occur after wire brushing jaws, then:

1. Stop machine.
2. Put shift lever in third speed.
3. Remove spindle cover.
4. Tighten brake adjustment bolt.
5. Start machine.
6. Push "stop button and spindle should coast $\frac{1}{4}$ - $\frac{1}{2}$ revolution. If not, repeat steps 4, 5 and 6.
7. Replace spindle cover.

66-A MAIN ASSEMBLY



THRED-O-MATIC "66-A" MAIN ASSEMBLY

NOTE:


For Machines Measuring 34 1/4" from Floor to Top Edge at Carriage End of Base Use:

- 41. 4752 Transmission Drive Belt, Single Phase (2)
- 4753 Transmission Drive Belt, Three Phase (2)
- 54. 15351-26 Oil Hose, Pump Outlet to Oil Tube Housing

1. 3404	Rear Jaw Housing Adapter Thumb Screw	34. F-206	Rail Att. Screw (8)	63. A-308	Single Phase, 220 V. 60 Cycle, 3 H.P. 1800 RPM
2. 6760	Spindle Cover Assy.	C-110	Rail Att. Lockwasher (8)	D-104	254 Frame Motor
13734	Lubricating Oil Cup (2)	B-102	Rail Att. Nut (8)	C-111	Motor Anchor Bolt (4)
13734	Oil Cup Elbow (2)	35. 4049	Rail (2)	B-103	Motor Anchor Flat Washer (4)
5. 6612	Spindle Gear	36. P-708	Carriage Pinion Pin	12046	Motor Anchor Nut (4)
6. 6626	Spindle Block — Front	37. 4617	Carriage Pinion Gear	12057	Oil Control Valve Assy.
7. 6611	Spindle Bearing — Front	38. 15870	Chip Tray	F-108	Oil Control Valve Assy. Bracket (2)
6611	Spindle Bearing — Rear	39. 4755	Transmission Sheave	B-101	Oil Control Valve Assy. Att. Screw (4)
J-906	Spindle Bearing Att. Screw (8)	40. 6665	Transmission Drive Belt (single phase) (3), See Note	D-103	Oil Pump Anchor Bolt (4)
YRS1075	Spindle Retaining Ring — Front	41.	Transmission Drive Belt (three phase) (3), See Note	C-110	Oil Pump Anchor Flat Washer (4)
9. N-702-H	Spindle Retaining Ring — Rear	42. 4420	Shift Lever	B-102	Oil Pump Anchor Nut (4)
10. 6840	Spindle Cover Att. Screw (4)	43. P-9061-A	Shift Lever Pin	15371	Oil Pump
11. 4654-2	Wheel Type Cutter Assy.	44. 6622	Shift Lever Extension Pin	N-503	Inspection Plate
12. H-205	Cutter Pivot Pin	45. 4421	Transmission	4330	Inspection Plate Att. Screw (4)
13. 6780	Die Head Assy.	46. 6662	21 T. Drive Gear	T-129	Motor Mounting Plate
15. 6820	Carriage Assy.	47. 4411	Transmission Bearing (2)	D-108	Motor Mounting Plate Shaft
16. 4215	Reamer Assy.	48. 4424	Transmission Pillow Block (2)	B-107	Motor Mounting Shaft Collar Pit (2)
17. 6661	Retaining Ring	49. 4675	Push Button Control Switch	Belt Adj. Nut (2)	
18. 6740	Jaw Housing Adapter — Rear	50. 4313	Push Button Control Switch Att. Screw (6)	Belt Adj. Washer	
19. 4207	Brake Band Assy.	51. 4680	Make-on Bar	U-926	Carriage Feed Wheel
20. N-503	Rear Oil Drip Shield — Rear Spindle Block	K-961	Make-on Bar Att. Screw (3)	72. 17549	Carriage Feed Rod
A-408	Rear Oil Drip Shield Att. Screw (2)	E-205	Oil Hose Fitting (8)	73. 4145	Base Assy.
D-205	Spindle Block Att. Flat Washer (8)	4513	Spindle Adjusting Screw	74. 4066	Oil Tube Fitting Inside "O" Ring
C-112	Spindle Block Att. Lock Washer (8)	A-104	Oil Hose, Strainer to Control Valve	75. 4087	Oil Drip Shield
B-104	Spindle Block Att. Nut. (8)	15351-13	Oil Hose, Pump Outlet to Oil Tube Housing, See Note	N-503	Oil Drip Shield Att. Screw (4)
21. 6627	Spindle Block — Rear	15351-21	Oil Hose, Control Valve to Pump Intake	H-202	Carriage Feed Rod Collar Set Screw
22. 4206	Front Oil Drip Shield — Rear Spindle Block	15351-23	Oil Hose, Oil Tube Housing to Relief Valve	H-202	Oil Reservoir Baffle Plate (Std. Eqpt. on Mobile Models)
N-503	Front Oil Drip Shield Att. Screw (2)	15351-12	Transmission Bearing Bushing (2)	78. 4567	Oil Tube Fitting Washer
23. 4033	Breakdown Extension Bar Assy.	4425	Set Screw, Bushing	79. 4572	Oil Tube Fitting Outside "O" Ring
24. 4569	Pipe Reducing Bushing	H-153	Transmission Att. Bolt	80. 4514	Oil Hose Clamp (8)
25. 4044	Pipe Elbow	A-407	Transmission Att. Flat Washer	81. 4015	Base Door Handle
26. 4540-1	Oil Tube Housing	D-105	Transmission Att. Lock Washer	K-956	Base Door Handle Att. Screw (4)
27. 6731	Pipe Tee	C-112	Transmission Att. Nut	B-133	Base Door Handle Att. Nut (4)
28. B-260	Oil Tube Fitting Jam Nut	B-104	Pressure Relief Valve Assembly	F-105	Carriage Feed Rod Bearing (2)
29. 6720	Spindle Assy.	76. 4630	Pressure Relief Valve Body	6762	Splash Guard
30. 4550	Strainer Assy.	4631	Pressure Relief Valve Spring	N-503	Splash Guard Att. Screw
31. 4770	Telescopic Oil Tube Fitting	4632	Pressure Relief Valve Ball		
32. 4356	Junction Box	4633	Pressure Relief Valve Adj. Screw		
N-702-H	Junction Box Att. Screw	4638	Pillow Block Att. Screw (4)		
13073	Junction Box Cover	F-509	Pillow Block Att. Lockwasher (4)		
4321	Single Phase Magnetic Switch, 220 V. 60 Cycle	C-113	Motor Sheave, Three Phase		
E-103	Three Phase Magnetic Switch, 220 V. 60 Cycle	59. 6785	Motor Sheave, Single Phase		
C-109	Magnetic Switch Att. Screw (2)	60. 15704	Oil Pump Drive Belt		
C-109	Magnetic Switch Att. Lockwasher (2)	61. 6786	Three Phase, 220-440 V. 60 Cycle, 5 H.P. 1800 RPM 213 Frame Motor		
B-101	Magnetic Switch Att. Nut (2)	62. 13051			

*See Detailed Schematic

TRANSMISSION ASSEMBLY NO. 6662 - EXPLODED VIEW




TRANSMISSION ASSEMBLY NO. 6662

- PARTS


1. 13401	Shaft, Shifter	26. 13422	Washer, Thrust (4)
2. 13402	Seal, Oil (2)	27. 13423	Plug, Pipe, 1/4"-27 NPT (2)
3. 13403	Plug, Expansion (2)	28. O-104	Pin, Dowel, 1/8"x1/4" Lg. (2)
4. 13404	Seal, Oil, Cover Bolt (4)	29. 13424	Plug, Pipe, 1/4"-18 NPT
5. A-317	Bolt, Cover Att., Hex. Hd., 3/4"-16x4" Lg. (4)	30. 13425	Shaft, Spine
6. 13405	Cover, Housing	32. 13427	Bearing, Ball w/Ret. Ring
8. 13407	Valve, Breather	34. 13429	Ring, Retaining (3)
9. 13408	Reducer, Pipe, 1/2" Male x 1/4" Female NPT	35. 13430	Seal, Oil (2)
10. 13409	Elbow, Pipe, Street, 1/2" x 90°	36. 13431	Gasket, Retainer Plate (2)
12. U-416	Pin, Spring, 1/8" x 1 1/8" Lg.	37. 13432	Retainer Plate (2)
13. 13410	Rod, Shifter, High	38. A-205	Bolt, Retainer Plate Att., Hex. Hd, 5/16-18x1" Lg. (9)
14. 13411	Rod, Shifter, Low	39. 13433	Plug, Expansion (2)
15. 13412	Finger, Shifter	40. H-106-D	Setscrew, 1/4"-20x1/2" Lg.
16. 13413	Bushing, Shifter Fork (2)	41. 13434	Housing
17. 13414	Ball, Shifter Lock (2)	42. 13435	Countershaft
18. 13415	Spring, Shifter Lock (2)	43. 13436	Spacer, Bearing
19. 13416	Bushing, Shifter Fork (2)	44. 13437	Bearing, Ball
20. 13417	Fork, Shifter (2)	45. 13438	Gear, High
21. H-305-A	Setscrew, Guide Bar, 3/4"-16x1/2" Lg. (2)	46. 13439	Bearing, Needle
22. 13418	Gear, Low	47. 13440	Gearshaft, Pinion -16T.
23. 13419	Gear, Cluster	49. 13441	Guide Bar
24. 13420	Spacer, Cluster Bearing	50. U-916	Pin, Spring, 1/4"x1 1/8" Lg. (2)
25. 13421	Bearing, Cluster Gear	51. 13442	Gasket, Cover

WHEEL TYPE CUTTER ASSEMBLY NO. 6840 2½"-6" RANGE

1. 4711 Handle, Cutter
2. F-107 Screw, Front Plate Att., ¼"-20x1" Soc. Hd. Cap (4)
3. 4652 Front Plate
4. 4656 Bearing, Thrust
5. 6649 Body, Cutter
6. 4126 Screw, Cutter Wheel
7. 4121 Wheel, Cutter
8. F-063 Screw, Bottom Plate., 10-32x¾" Soc. Hd. Cap (6)
9. 4117 Roller, Cutter (2)
10. 1124 Screw, Roller (2)
11. 4651 Roller Block
12. 4103 Screw Cutter
13. P-906f-A Pin, Handle Att., ¼"x1½" Grooved
14. B-103 Nut, Cutter Wheel Att., ¾-16 Hex
15. C-111-M Lock Washer, Cutter Wheel Att., ¾"
16. 4653 Bottom Plate
17. 1023-22 Oil Cut




Adjustable Cone Reamer Assembly #10060



1. 13212 Reamer, Cone, 5-Flute
2. 10065 Holder, Cone Reamer
3. P-707-A Pin, Grooved, Knob Att., 3/16"x1¼" Lg.
4. 1652 Knob, Cone Reamer
5. F-607-S Screw, Reamer Att., ¾-11x1½" Lg., Soc. Hd. Cap
6. 2139-1 Spacer, Reamer Att.


SPINDLE ASSEMBLY NO. 6720



- | | |
|---------------|------------------------------|
| 1. Y-5100-100 | Jaw Retaining Ring (8) |
| 2. 6751 | Jaw (8) |
| 12875 | Jaw Set, R&L (8) |
| 3. W-810 | Jaw Lever Key (4) |
| 4. 4211 | Jaw Shaft (4) |
| 5. YKSA-1075 | Spindle Retaining Ring, Rear |


- | | |
|--------------|--------------------------------|
| 6. 6625 | Spindle |
| 7. 4212 | Jaw Lever and Pin Assembly (4) |
| 8. 6612 | Spindle Gear |
| 9. YKSA-1075 | Spindle Retaining Ring, Front |
| 10. W-810 | Jaw Key (8) |

BRAKE-BAND ASSEMBLY NO. 12582



- | | |
|-------------|---------------------------|
| 3. B-103 | Adjustment Nut |
| 4. DA-104-W | Spring Flat Washer |
| 5. 4263 | Spring, Compression |
| 7. 12583 | Brake Shoe & Lining Assy. |
| 8. 4261-1 | Adjustment Bolt |

BLADE REAMER ASSEMBLY NO. 6820 2½"-6" RANGE




- | | |
|------------|--------------------------------------|
| 1. 6617-1 | Holder Reamer |
| 2. H-305-D | Set Screw, Reamer Att., ¾-16x1½" (2) |
| 3. 4943-1 | Handle, Reamer |
| H-508-D | Set Screw, Handle Att., ½-13x1¼" |
| 4. 12237 | Reamer, Inside, 2½"-4" |
| 12238 | Reamer, Inside, 5"-6" |

GROOVER HEAD ASSEMBLIES

NOTE: Centering dies are included in die head assembly.

Part No. HEAD ASSEMBLIES


- 12124 2½"-3" Die head assembly for grooving & beveling, less tool bits
12125 3½"-4" Die head assembly for grooving & beveling, less tool bits
12107 5"-6" Die head assembly for grooving & beveling, less tool bits



- | | | | |
|-------------|---|-------------|---|
| 1. 4905 | Retainer, Scroll Plate, 2½"-4" | 17. 12227 | Screw, Feed |
| 6605 | Retainer, Scroll Plate, 5"-6" | 18. 12319 | Cut-Off Tool, 2½"-6" |
| 2. 12122 | Scroll Plate, 2½"-4" | 12229-40 | Grooving Tool, Sch. 40 Pipe, 2½"-6" |
| 12123 | Scroll Plate, 5"-6" | 12229-80 | Grooving Tool, Sch. 80 Pipe, 2½"-6" |
| 3. 6602 | Lever, Operating. Includes: O-406 Dowel Pin | 12213 | Double Bevel Tool, 37½ degrees, 2½"-6" |
| 4. A-102 | Screw, Hex Hd. Cap. ¼-20x½" (4) | 12268 | Double Bevel Tool, 45 degrees, 2½"-6" |
| 5. L-1100 | Screw, Round Head Mach., ¼-20x¼" (2) | 12218 | Saran Tool, 2½"-6" |
| 6. 12228 | Cover, Die Slot Extension | 19. 6609-1 | Selector Plate, 2½" |
| 7. 12101 | Die, Centering, 2½"-3" (4) | 6609-2 | Selector Plate, 3" |
| 12104 | Die, Centering, 3½"-4" (4) | 6608-1 | Selector Plate, 3½" |
| 12102 | Die, Centering, 5"-6" (4) | 6608-2 | Selector Plate, 4" |
| 8. 14895 | Housing, Groover, 2½"-4" | 6601-1 | Selector Plate, 6" |
| 14897 | Housing, Groover, 5"-6" | 6606-2 | Selector Plate, 6" |
| 9. 12235 | Plug, Expansion | 20. H-103-A | Set Screw, ¼-20 x 5/16" |
| 10. O-408 | Dowel Pin, 5/16"x1¼" | 21. 12094 | Bearing Block |
| 11. 12215 | Handle, Feed Screw | 22. 4943-1 | Handle, Die Head |
| 12. P-706-A | Grooved Pin, 3/16"x1" | H-508-D | Set Screw, ½-13x1½" |
| 13. 12097 | Indicator, Groove Depth | 23. B-105 | Nut, Hex., ½-13 |
| 14. F-209 | Screw, Soc. Hd. Cap. 5/16-18x1¼" (2) | 24. A-505-P | Screw, Hex. Hd. Cap. ½-13x1½" |
| C-110 | Lock Washer, 5/16" (2) | 25. F-208 | Screw, Soc. Hd. Cap. 5/16-18x1½" for 2½"-4" (5) |
| 15. F-105 | Screw, Soc. Hd. Cap. ¼-20x¾" | F-210 | Screw, Soc. Hd. Cap. 5/16-18x2" for 5"-6" (5) |
| B-101 | Nut, Std. Hex., ¼-20 | 26. 12226 | Extension, Die Slot |
| 16. 12096 | Bearing, Thrust (2) | | |

SNAP-O-MATIC DIE HEAD ASSEMBLIES 2½"-6"

1. 4805 Retainer, Scroll Plate, 3½"-4"
- 4906 Retainer, Scroll Plate, 2½"-3"
- 6605 Retainer, Scroll Plate, 6"
- 6638 Retainer, Scroll Plate, 5"
2. 6601 Scroll Plate, 2½"-4"
- 6603 Scroll Plate, 5"-6"
3. 6602 Lever, Operating (includes O-406 Dowel Pin)
4. A-102 Screw, Hex Hd. Cap, Selector Plate Att., ¼-20x½" (4)
5. 6639 Stop, Scroll Plate
- F-103 Screw, Soc. Hd. Cap, Stop Att., ¼-20x½" (2)
7. Dies, Set of (5). Specify size and type of Thread Desired (e.g. 2½" and 3" NPT)
8. 14808 Housing, Die Head, 6"
- 14894 Housing, Die Head, 3½"-4"
- 14898 Housing, Die Head, 2½"-3"
- 17537 Housing, Die Head, 5"
9. 12235 Plug, Expansion
10. O-406 Dowel Pin, Operating Lever, 5/16"x1¼" lg.
11. 6606-1 Selector Plate, 5"
- 6606-2 Selector Plate, 6"
- 6608-1 Selector Plate, 3½"
- 6608-2 Selector Plate, 4"
- 6609-1 Selector Plate, 2½"
- 6609-2 Selector Plate, 3"
12. H-503-D Set Screw, Die Head Centering, ½-13x½" lg.
13. A-504-P Screw, Hex. Hd. Cap, Handle Att., ½-13x1¼" lg.
- C-113-M Lock Washer, Handle Att., ½"
14. A-505-P Screw, Hex. Hd. Cap, Die Head Centering, ½-13x1½" lg.
15. 6950 Handle, Die Head
16. F-208 Screw, Soc. Hd. Cap, Retainer Att., 5/16-18x1½" lg. (5) for 2½"-4" Housing
- F-210 Screw, Soc. Hd. Cap, Retainer Att., 5/16-18x2" lg. (5) for 5"-6" Housing




SNAP-O-MATIC DIE HEAD ASSEMBLIES 1/8" - 2"

DUAL SNAP-O-MATIC DIE HEADS: ⅛" & ¼" & ⅜" & ½" & ¾" & 1" & 1¼" & 1½" & 2"


QUAD SNAP-O-MATIC DIE HEAD: 1" - 2"

1. F-053 Die Head Soc. Hd. Cap Screw, 10-24x¾" (4)
- C-107-HC Lockwasher, Hi Collar, No. 10
2. 1433 1"-2" Retainer Plate
- 1673 ⅝"-¾" Retainer Plate
3. 1632 1"-2" Scroll Plate
- 1642 ⅝"-¾" Scroll Plate
4. 1633 Operating Lever
5. O-406 Operating Lever Pivot Dowel Pin, 5/16"x1¼"
6. 1634-1 1"-1¼"-1½" Selector Plate
- 1635-1 1" Selector Plate
- 1635-2 1¼" Selector Plate
- 1636-2 2" Selector Plate
- 1644-1 ½" Selector Plate
- 1644-2 ¾" Selector Plate
- 1645 ¼" & ⅜" Selector Plate
- 1646 ⅝" Selector Plate
7. CC-109-AP Washer, Tooth Lock, External, ¼"
- G-104-S Selector Plate Att. Button Hd. Cap Screw, ¼-20x¾" (4)
8. F-107 Scroll Plate Stop Soc. Hd. Cap Screw, ¼-20x1"
9. 13113 Scroll Plate Spacer
10. 1631 1"-2" Die Head Housing
- 1641 ⅝"-¾" Die Head Housing
16. 1431-1 Die Head Pin
17. Set of (4) Dies, Specify Size and Type (e.g. ½" NPT)
18. 13385 Ball
19. 12220 Spring
20. 12135 Expansion Plug




CARRIAGE ASSEMBLY NO. 6780

- | | |
|----------------|---|
| 1. 23101 | Die Head and Reamer Stop |
| 2. E-206 | Die Head and Reamer Stop Att. Screw (3) |
| 3. 4657 | Flexible Coolant Spout |
| 4. 4658 | Valve, Plug, $\frac{1}{8} \times \frac{1}{8}$ |
| 5. 4556 | Elbow, Street, $\frac{1}{8} \times \frac{1}{8} \times 90^\circ$ |
| 6. 3404 | Carriage Locking Thumbscrew |
| 7. 6732 | Wear Button |
| 8. 6616-1 | Carriage |
| 9. 4655 | Cutter Rest Pin |
| 10. 4563 | Cutting Oil Telescopic Tube |
| 11. 4654-2 | Cutter Pivot Pin |
| 12. 4919 | Cutter Wear Plate (2) |
| 13. 4917 | Carriage Pin |
| 14. H-205-D | Cutter Pivot Pin Set Screw (2) |
| 15. Y-5100-100 | Reamer Retaining Ring |




ADAPTER ASSEMBLY FOR 1"-2" DIE HEADS NO. 6920

- | | |
|------------|--|
| 1. 6921 | Adapter |
| 2. 10053 | Pin, Die Head |
| 3. 1572 | Pin, Headed, Die Head Stop |
| 4. A-505-P | Screw, Hex. Hd. Cap, Adapter Centering $\frac{1}{2}$ -13x1 $\frac{1}{2}$ " lg. |
| 5. H-503-D | Set Screw, Adapter Centering, $\frac{1}{2}$ -13x $\frac{1}{2}$ " long |
| 6. H-104-D | Set Screw, Cutter Pin, $\frac{1}{4}$ -20x $\frac{1}{4}$ " lg. |
| 7. 13056 | Pin Pivot Cutter |



OIL LINE SCHEMATIC






- | | | | |
|-----------------|--|--------------|--|
| 1. 4572 | "O" Ring, Outside | 14. 12232 | Nipple, Pipe, $\frac{3}{8}$ " x $1\frac{1}{2}$ " |
| 2. 4567 | Washer | 15. 4630 | Valve Assembly, Pressure Relief Includes: |
| 3. B-280 | Nut, $\frac{3}{8}$ -14 Hex. Jam | | 4631 Body, Pressure Relief Valve |
| 4. 4770 | Fitting, Oil Tube, Telescopic | | 4632 Spring, Pressure Relief Valve |
| | "O" Ring Inside | | 4633 Ball, Pressure, Relief Valve |
| 5. 4542 | Coupling, Pipe, $\frac{1}{2}$ " | | 4638 Screw, Adjusting, Pressure Relief Valve |
| 6. 4540-1 | Housing, Oil Tube | | St. Elbow, Pipe, $\frac{3}{8}$ " (3) |
| 7. 4044 | Reducer, Pipe, $\frac{1}{2}$ " | 16. 4024 | Strainer, Oil |
| 8. 4569 | Elbow, Pipe, $\frac{1}{2}$ " | 17. 4550 | Hose, Oil $\frac{3}{8}$ " x 27" |
| 9. 12233 | Nipple, Pipe, Thd. one end, $\frac{3}{8}$ " x 2" (2) | 18. 15351-27 | Valve, Oil Control |
| 10. 15371 15370 | Oil Pump Assembly (Pump + Bracket) | 19. 12238 | Hose, Oil, $\frac{3}{8}$ " x 16" |
| 11. 15351-19 | Hose, Oil $\frac{3}{8}$ " x 19" | 20. 15351-18 | Elbow, Pipe, $\frac{1}{2}$ " |
| 13. 12234 | Tee, Pipe, $\frac{3}{8}$ " | 21. 12437 | Clamp, Oil Hose (8) (Not Shown) |

LUBRICATOR ASSEMBLY

PART NO. 13734

OPERATING INSTRUCTIONS


1. Before operating machine lift and release plunger six times on lubricator.
2. Lubricate every two hours of operation (lift and release plunger once)
3. Keep reservoir of lubricator filled with SAE 30 oil.
4. Replace filter element (Part No. 13753) on lubricator pump once a year.



- | | | |
|-----|----------|-------------------------------------|
| 1. | 13735 | Lubricator |
| 2. | 13753 | Filter Element (Included in #13735) |
| 3. | G-104-S | Screw (2) |
| 4. | CB-109-A | Lockwasher (2) |
| 5. | 13754 | Plate, instruction |
| 6. | 13736 | Sleeve, compression (6) |
| 7. | 13737 | Bushing, compression (6) |
| 8. | 13739-21 | Tubing, 21" lg. |
| 9. | 13738 | Junction |
| 10. | 13739-25 | Tubing, 25" lg. |
| 11. | 13739-25 | Tubing, 25" lg. |
| 12. | 13739-26 | Tubing, 26" lg. |
| 13. | F-107 | Screw |
| 14. | C-109-M | Lockwasher |
| 15. | D-102 | Flat washer (2) |



THRED-O-MATIC "66-A" WIRING DIAGRAMS

THREE PHASE



DIE SEGMENT INDEX





P = PIPE
C = CONDUIT





No. 2584

No. 2586C

Series "44-A" and "66-A" Snap-O-Matic (5 segments)



Series "66A"



Part No. 6677
Part No. 6681

***NOTE: This page
is left blank!***

THREAD SIZES AND SPECIFICATIONS

DIMENSIONS				U.S. STANDARD								BRITISH STANDARD					METRIC						
PIPE INSIDE DIA.	NOMINAL SIZE	BOLT & TUBE OUTSIDE DIA.	MAJOR DIAMETER OF THREAD	MAJOR DIAMETER OF THREAD	PIPE, TAPERED N.P.T.	PIPE, PARALLEL (CONDUIT) N.P.S.	BOLT, NATIONAL COARSE U.N.C.	BOLT, NATIONAL FINE, U.N.F.	CONSTANT PITCH		API CASING LONG THD.	API TUBING NON-UPSET THD.	API TUBING UPSET, REG. THD.	PIPE, TAPERED B.P.T.	PIPE, PARALLEL B.P.P.	CONDUIT BSC (BSC)	BOLT, WHITWORTH B.S.W.	BOLT, PINE B.P.F.	COARSE ISO	FINE ISO	METRIC CONDUIT		
									8 U.N.	11 U.N.													
			INCH	MILLIMETER	THREADS PER INCH								THREADS PER INCH					PITCH IN MM					
		.312	4.0																	1.0			
	1/4	.250	6.35				20	28										20	24	1.0			
		.215	7.0																				
	5/16	.312	7.94				18	24										18		1.25	1.0		
		.315	8.0																	1.25	1.0		
		.354	9.0																				
	3/8	.375	9.52				16	24										16	20				
	1/2	.381	9.73											28	28								
		.394	10.0																	1.5	1.0		
	1/2	.404	10.27		27	27																	
		.433	11.0																	1.5	1.0		
	7/16	.437	11.11				14	20										14	18	1.75	1.5		
		.472	12.0																				
	1/2	.500	12.7				12	20										12	16				
	1/2	.518	13.14											19	19								
	1/2	.534	13.57		18	18														2.0	1.5		
		.551	14.0																				
	9/16	.542	14.29				12	18										12	14				
		.591	15.0																				
	5/8	.475	15.87				11	18										11	14	2.0	1.5	1.5	
		.620	16.0																				
	3/2	.654	16.64											19	19								
		.649	17.0																				
	3/2	.671	17.05		18	18														2.5	1.5		
		.709	18.0																				
	3/4	.75	19.05				10	16										16	10	12	2.5	1.5	1.5
		.787	20.0																				
	1/2	.875	20.15											14	14								
	1/2	.834	21.27		14	14														2.5	1.5		
		.846	21.0																				
	7/8	.875	22.22				9	14										9	11	3.0	2.0		
		.945	24.0																				
		.984	25.0																	3.0	2.0	1.5	
	1	1.0	25.4				8	12		12								14	8	10			
		1.024	26.0																				
	3/4	1.041	26.44											14	14								
	3/4	1.044	26.57		14	14														3.0	2.0		
		1.043	27.0																				
		1.102	28.0																				
	1 1/8	1.125	28.57				7	12	8									7	9	3.5	2.0		
		1.181	30.00																				
	1 1/4	1.25	31.75				7	12	8									14	7	9			
		1.24	32.00																	3.5	1.5	1.5	
		1.299	33.00																				
	1	1.308	33.23		11.5	11.5																	
		1.309	33.25											11	11								
	1 3/8	1.375	34.92				6	12	8									6	8				
		1.378	35.0																				
		1.417	36.0																	4.0			
		1.457	37.0																				
		1.496	38.0																				
	1 1/2	1.50	38.1				6	12	8									14	6	8	4.0		
		1.53	39.0																		1.5	1.5	
		1.575	40.0																				
	1 5/8	1.625	41.27				5.5	8										5					
	1 1/4	1.65	41.91											11	11								
	1 1/4	1.653	41.99		11.5	11.5														4.5			
		1.653	42.8																				
		1.732	44.0																				
	1 3/4	1.75	44.45				5	8	12									5	7	4.5			
		1.772	45.0																				
	1 7/8	1.875	47.62				5	8	12									4.5					
	1 1/2	1.882	47.87											11	11								
		1.89	48.0																	5.0			
	1 1/2	1.892	48.05		11.5	11.5																	
		1.948	50.0																		1.5	1.5	
	2	2.0	50.8				4.5	8	12									14	4.5	7			
		2.047	52.0																	5			
	2 1/4	2.25	57.15				4.5											4					
	2	2.247	59.61											11	11								
	2	2.246	60.09		11.5	11.5																	
	2 3/4	2.349	60.17								10												
	2 1/2	2.50	63.5				4											14					
	2 1/2	2.623	66.84									8											
	2 3/4	2.75	69.85				4																
	2 1/2	2.842	72.7		8	8																	
	2 7/8	2.849	72.87									10											
	2 1/2	2.94	75.18											11	11								
	3	3.0	76.2																				
	3 1/2	3.196	81.18				4							8									
	3 1/4	3.25	82.55				4											11	11				
	3	3.44	87.88																				
	3	3.488	89.61		8	8																	
	3 1/2	3.494	89.75								10												
	3 1/2	3.5	88.9				4																
	3 3/4	3.75	95.25				4																
	3 5/8	3.81	96.77											8									

LIFETIME WARRANTY

ROTHENBERGER USA, INC., warrants all our products against defects in materials or workmanship. This warranty covers replacement or repair of defective parts for the lifetime of the product (excluding motors and electrical parts, which are warranted for a period of one year from date of sale), provided that failure is not due to abuse, abnormal use, or by normal wear and tear. NO OTHER WARRANTY, EITHER WRITTEN OR ORAL, SHALL APPLY. Pipe and drain cleaning tools and cables are not covered by this warranty and are considered expendable materials.

Products must be returned, freight prepaid, to ROTHENBERGER USA, INC. If the warranty applies, the product will be repaired or replaced at no charge to the customer and returned freight prepaid. Only ROTHENBERGER USA, INC. can make warranty judgments and we retain the right to the final decision regarding warranty application. THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS. IN NO EVENT DOES ROTHENBERGER'S USA, INC. LIABILITY EXTEND BEYOND REPAIR OR REPLACEMENT OF ITS PRODUCT WARRANTED ABOVE.



955 Monterey Pass Road • Monterey Park, CA 91754
Tel 323-268-1381 Fax 323-260-4971
www.rothenberger-usa.com