



TECHNOLOGY GROUP

100

DISPLAY UP ^ SET >

LIMITS DOWN v SET <

BOOM JOB CONFIG DEDUCT

BYPASS ESC RIG ENTER

HOIST

PARTS

CONFIG

DEDUCT

RIG

ENTER



RIGHT SWING LEFT

EXT. TELE

LOWER BOOM RAISE

DOWN LEFT UP

DOWN RIGHT UP

CAUTION
DO NOT PICK AND CARRY WITH BOOM EXTENSION INSTALLED

CAUTION
THE LOAD HOIST LINE ON THIS UNIT MUST BE 9/16" DIA., 6 X 37 1/2IP-1WIRC-WIRE ROPE (OR EQUIVALENT) WITH A MINIMUM BREAKING STRENGTH OF 31,500 LB. ROPE IN GOOD CONDITION. THE MAX. LOAD WITH SINGLE PART LINE IS

LOWE HOIST RAISE

WARNING
OPERATOR MUST KEEP ALL PARTS, ESPECIALLY THE HOIST LINE, UNDER CONSTANT WHILE OPERATING.

TURN KEY OFF

TURN KEY OFF

ENGINE KILL



OIL TEMPERATURE
MAX. TEMP 200°



OFF ACC RUN

ENGINE STARTING
1. TURN IGNITION SWITCH ON
2. PRESS THIS (GLOW PLUG) BUTTON FOR 15 SECONDS IF TEMP. ABOVE 32° F. PRESS FOR 30 SECONDS IF BELOW 32° F.
3. START ENGINE
4. DO NOT USE EITHER

START

HUSS CONTROL

Filter 100 %

C M F

Start Stop

HORN